



NOTES:

1. LOCATE FB-q TERMINATION ABOVE ANTICIPATED WATER LEVEL. FLEECE-BACKING MUST BE REMOVED AT COMPRESSION SEAL TERMINATIONS (FB-q-A & D). REFER TO SPECIFICATIONS.
2. FOR CORNER APPLICATIONS, SEE FB-15 DETAILS.
3. 6" (150 mm) WIDE PRESSURE-SENSITIVE UNCURED ELASTOFORM FLASHING® MUST BE CENTERED OVER ALL SPLICES.
4. IF SELVAGE EDGE IS PROVIDED ON FLEECEBACK MEMBRANE USED AS FLASHING, FOLLOW SPLICE PROCEDURES OUTLINED ON DETAILS FB-12-C OR D.

FB-12-B

PARAPET/CURB - FleeceBACK MEMBRANE FLASHING



Carlisle Syntec Incorporated