



- NOTES:
1. PRIOR TO INSTALLATION OF SecurTAPE, APPLY SURE-SEAL PRIMER TO SPLICE AREAS.

2. SecurTAPE IS TO BE OVERLAPPED A MINIMUM OF 1" (25 mm) AT THE ENDS OF EACH CUT PIECE. OVERLAY TAPE OVERLAPS WITH LAP SEALANT. REFER TO DETAIL FB-2-B.

3. SURE-SEAL PRESSURE-SENSITIVE T-JOINT COVER OR 6" (150 mm) WIDE PRESSURE-SENSITIVE UNCURED ELASTOFORM FLASHING MUST BE CENTERED OVER FIELD SPLICE.

4. LOCATE FB-9 TERMINATION ABOVE ANTICIPATED WATER LEVEL. FLEECE-BACKING MUST BE REMOVED AT COMPRESSION SEAL TERMINATIONS (FB-9-A AND D). REFER TO SPECIFICATIONS.

5. FOR CORNER APPLICATIONS, SEE FB-15 DETAILS.

## FB-12-C

### PARAPET/CURB WITH CURED EPDM (SecurTAPE)