



NOTES:

1. SEAL ALL EDGES WITH LAP SEALANT.
2. IN-SEAM SEALANT IS REQUIRED ON ALL VERTICAL ADHESIVE SPLICES BETWEEN ADJOINING SECTIONS OF CURED MEMBRANE.
3. FOR USE OF SURE-SEAL INSIDE CORNER FLASHING, REFER TO DETAIL FB-15-F.
4. PRESSURE-SENSITIVE CURED COVER STRIP OR OVERLAYMENT STRIP CANNOT BE USED AT CORNERS. PRESSURE-SENSITIVE UNCURED ELASTOFORM FLASHING OR SURE-SEAL INSIDE/OUTSIDE CORNERS MUST BE USED.

FB-15-A

INSIDE CORNER/CONTINUOUS FleecEBack MEMBRANE



Carlisle Syntec Incorporated