



NOTES:

1. WOOD NAILER MUST EXTEND PAST TOTAL WIDTH OF SecuredGE DECK FLANGE.
2. 6" (150 mm) WIDE UNCURED ELASTOFORM FLASHING® OR PRESSURE-SENSITIVE FLASHING MAY ALSO BE CENTERED OVER FIELD SPLICE AT ANGLE CHANGE.
3. REFER TO SecuredGE 200 INSTALLATION INSTRUCTION MANUAL FOR STEP-BY-STEP INSTALLATION PROCEDURES.
4. LAP SEALANT IS OPTIONAL WITH TAPE SPLICES (REFER TO SPECIFICATIONS).
5. FASTENING OF METAL WORK BY OTHERS AS RECOMMENDED BY MANUFACTURER.

FB-1-A (Option 2)

CARLISLE SecuredGE™ 200

**CARLISLE**  
Carlisle SynTec Incorporated