



NOTES:

1. DECK FLANGE MUST BE TOTALLY COVERED BY PRESSURE-SENSITIVE FLASHING WITH MINIMUM 2" (50 mm) COVERAGE PAST NAIL HEADS.
2. TO REMOVE FINISHING OILS, SCRUB METAL FLANGE WITH WARM SOAPY WATER AND RINSE WITH CLEAN WATER; ALLOW TO DRY PRIOR TO APPLYING PRIMER.
3. APPLY SURE-SEAL PRIMER TO METAL FLANGE AND EPDM MEMBRANE SURFACE PRIOR TO INSTALLING PRESSURE-SENSITIVE FLASHING.
4. LAP SEALANT MUST BE APPLIED AT FLASHING OVERLAPS AND INTERSECTIONS WITH JOINTS IN METAL EDGING.

#B-1-B

SURE-SEAL® DRIP EDGE / PRESSURE-SENSITIVE FLASHING



Carlisle SynTec Incorporated