



NOTES:

1. PRIOR TO INSTALLATION OF SureTape, APPLY SURE-SEAL PRIMER TO SPLICE AREAS.
2. SureTape IS TO BE OVERLAPPED A MINIMUM OF 1" (25 mm) AT THE ENDS OF EACH CUT PIECE. OVERLAY TAPE OVERLAPS WITH LAP SEALANT AS SHOWN ABOVE.
3. AT FIELD SPLICE INTERSECTIONS, APPLY A PRESSURE-SENSITIVE "T" JOINT COVER OR 6" (150 mm) WIDE SECTION OF PRESSURE-SENSITIVE UNCURED ELASTOFORM FLASHING®. REFER TO DETAIL FB-2-C.
4. REFER TO DETAIL FB-2-E FOR END LAP SPLICING PROCEDURES.

FB-2-B
MEMBRANE SPLICE WITH SureTape™

