



NOTES:

1. APPLY SURE-SEAL PRIMER TO MEMBRANE SURFACES PRIOR TO INSTALLING CURED COVER STRIP.
2. APPLY SURE-SEAL PRESSURE-SENSITIVE T-JOINT COVERS AT FIELD SPLICE INTERSECTIONS AS SHOWN ABOVE AND AT FLASHING OVERLAYS AS SHOWN ON DETAIL FB-1-B (OPTION 2).
3. REFER TO SPECIFICATION FOR PROJECTS WITH 20 YEAR WARRANTY.

FB-2-E

END LAP SPLICE / CURED COVER STRIP

**CARLISLE**  
Carlisle Syntec Incorporated